US ERA ARCHIVE DOCUMENT

# Session 10 Subpart X Miscellaneous Units



Booz | Allen | Hamilton

## Session 10 Agenda: Subpart X Miscellaneous Units

- Regulatory Background
- Goals and Definition
- Permitting Considerations
- Performance Objectives
- Environmental Performance Assessments
- Closure





## **Regulatory Background**

- Why were regulations developed for miscellaneous units?
  - Practices did not fit definition of other units
  - Includes innovative technologies under RCRA permit authority
- Where are the regulations for miscellaneous units?
  - Interim Status:

Part 265, Subpart P (Thermal Treatment)

Part 265, Subpart Q (Chemical, Biological, or Physical Treatment)

Part 265, Subpart R (Underground Injection Control [UIC] Wells)

– Permitted Facilities:

Part 264, Subpart X (All Miscellaneous Units except UIC wells, which are now covered by the Safe Drinking Water Act)



## Goals of the Miscellaneous Units Regulations

- Designed to regulate innovative technologies and those waste management practices not previously addressed
- General requirements, not technology-specific
- Units are required to be located, designed, constructed, operated, maintained, and closed in a manner that will prevent any unsafe releases to the groundwater, subsurface environment, surface water, wetlands, soil surface, or air
- Media- or pathway-based approach with Agency flexibility to tailor requirements to unique waste management practices



## **Miscellaneous Unit – Definition**

"A hazardous waste management unit where hazardous waste is treated, stored, or disposed of and that is not a container, tank, surface impoundment, pile, land treatment unit, landfill, incinerator, boiler, industrial furnace, UIC well, containment building, corrective action management unit, unit eligible for a research, development, and demonstration (RD&D) permit, or staging pile"

### Examples:

- Open burning and open detonation (OB/OD) units
- Burn pans
- Deactivated missile silos
- Salt domes and other geologic waste repositories (e.g., WIPP)
- Biological treatment units



## **OB/OD Units**

- Most typical Subpart X unit
- High potential for impact operations are required to be performed on the ground or in treatment devices that are open to the air
- Major permitting issues
  - Definition of "Potential to Detonate"
  - Containment
  - Air assessment
  - Sampling and monitoring
     Analytical issues and detection limits
     Groundwater monitoring
     Unsaturated zone monitoring and soil sampling
  - Frequently located on active impact ranges





## **Miscellaneous Units – Permitting**

- Describe the unit's physical characteristics, construction materials, and dimensions
- Provide detailed plans and engineering reports describing the unit location, design, construction, operation, maintenance, monitoring, inspection, and closure
- OB/OD Example (Burn Pans, Burn Vaults, Burn Cylinders)
  - Engineered diagrams and PE certifications
  - Operating procedures and frequencies
  - Inspection, monitoring, and maintenance plan
  - Ash and residue management plans
  - Stormwater management plans



Detonation of Unexploded Ordnance in Burn Pans







## Performance Objectives for Subpart X Miscellaneous Units

- Difficult to set technology-based design and operating standards for diverse group of units
- Instead, performance-based objectives were established requiring facilities to:
  - Evaluate the potential environmental impacts of the unit across all media
  - Demonstrate that the unit will not adversely affect human health and the environment
- OB/OD units must also demonstrate the alternate technologies are unavailable or infeasible



## **Environmental Performance Assessments**

- Quality and physical and chemical characteristics of waste
- Hydrogeological characteristics of site
- Protection of groundwater
- Protection of surface water, wetlands, and soil
- Air quality assessments/air dispersion monitoring
- Human health and ecological risk assessments
  - Risks for both current and future contamination



## Miscellaneous Unit – Closure

- Units that cannot be clean-closed require post-closure care
- During post-closure, miscellaneous units must meet all of their established unit-specific environmental performance standards, as well as appropriate postclosure standards of Part 264, Subpart G



Permanent placement of waste in geologic repository – Carlsbad, NM

